ARKEMA

WATER SOLUTIONS WITH KYNAR® PVDF



Drivers in the Market

URBANIZATION

Poor quality of

ground/surface water

Scarcity of freshwater

CLEAN WATER

PLANT FOOTPRINT

Plants are required to operate beyond their design capacity/capabilities

SEVERE CHEMICALS

Cl → ClO₂ , NaOCl, and Chloramines

Much more extreme oxidization

A Variety of end Applications



Problematic Cycle in Agriculture Water



Classifications of Membranes





A Common Thread of Requirements



Halogen Resistance

Chloramine resistance	Chlorine dioxide resistance
	Chloramine resistance

Acid & Oxidizer Resistance

Hydrochloric acid resistance

Sulfuric acid resistance

Hydrogen peroxide resistance Citric acid resistance

Also good resistance to **aromatics, chlorinated solvents,** and **hypochlorous acid (HOCl)**

Chemical Resistance of Kynar® PVDF



■ PVDF ■ PES ■ PSu

0.2µm samples exposed for 14 days @ 45°C

Longer Lifetime and more Forgiving

Kynar® PVDF High ductility

High elongation Good resilience

Flexibility and Toughness

Processing Benefits of Kynar[®] PVDF

Kynar[®] PVDF for Filtration Membrane

Grade	Melt Visc (kp)	Solution Visc (cps)	Notes
741	16 – 22	100 – 200	Good for TIPS HF
761	25 – 29	300 - 450	Sheet membranes and TIPS HF
761A	30.5 - 35.5	850 - 1400	Sheet membranes or hollow fiber
MG15	35 – 38	1500 – 1900	Ideal for hollow fiber

Kynar[®] PVDF for Macro-void-free Membranes

KYNAR[®]

Arkema's Service

• Model formulation

- Membrane spinning conditions
- \circ On-site lab trials and training
- Field technical support
- \circ Characterization
- Global support

Let us save you YEARS of R&D

Kynar[®] PVDF Global Footprint

© Copyright 2021 Arkema – All rights reserved. Do not copy without express permission from Arkema.

Rilsan®, Pebax®, Rnew®, Virtucycle®, Kynar®, Kynar 500®, Kynar Aquatec®, Kepstan®, Orgasol®, FSF® are registered trademarks of Arkema.

Arkema strictly prohibits the use of any polymers, including medical grades, in applications that are implanted in the body or in contact with bodily fluids or tissues for greater than 30 days. Unless Arkema otherwise expressly agrees by written contract, the Arkema trademarks and the Arkema name shall not be used in conjunction with customers' medical devices, including without limitation, permanent or temporary implantable devices, and customers shall not represent to anyone else, that Arkema allows, endorses or permits the use of Arkema products in such medical devices. Further, all implantable medical devices, whether permanent or temporary, carry a risk of adverse consequences. With regard to implantable medical devices, you should not rely upon the judgment of Arkema. Any decision regarding the appropriateness of a particular medical device in a particular medical application or for a specific clinical use should be based upon the judgment of your physician, medical device supplier and the United States Food & Drug Administration and/or the European process of Medical Device notification. Unless otherwise specifically stated by Arkema in writing, Arkema does not perform clinical medical studies on implantable medical devices. Arkema cannot weigh the benefits against the risks of a device and does not offer a medical judgment on the safety or efficacy of use of any Arkema product in a medical device. The statements, technical information and recommendations contained herein are believed to be accurate as of the date hereof. Since the conditions and methods of use of the product and of the information referred to herein are beyond our control, ARKEMA expressly disclaims any and all liability as to any results obtained or arising from any use of the product or reliance on such information; NO WARRANTY OF FITNESS FOR ANY PARTICULAR PURPOSE, WARRANTY OF MERCHANTABILITY OR ANY OTHER WARRANTY, EXPRESSED OR IMPLIED, IS MADE CONCERNING THE GOODS DESCRIBED OR THE INFORMATION PROVIDED HEREIN. THE information provided herein relates only to the specific product designated and may not be applicable when such product is used in combination with other materials or in any process. The user should thoroughly test any application before commercialization. Nothing contained herein constitutes a license to practice under any patent and it should not be construed as an inducement to infringe any patent and the user is advised to take appropriate steps to be sure that any proposed use of the product will not result in patent infringement.

ARKEMA

arkema.com